

**CLEANING INSTRUCTIONS FOR DRAPERIES  
FROM BARWICK MANUFACTURING**

Top fabric     100% polyester  
Lining         Roclon blackout

Because of backing: 1) Dry clean only!  
                              2) Fluff in dryer  
                              3) Spot clean

CAUTION: Do not expose lining to temperatures above 120F or below 32F

Dry cleaning instructions:

1. Inspect draperies for labels that recommend special care.
2. Make sure draperies have been measured before cleaning, pass information on to finisher.
3. Remove all drapery hooks/pins and inspect for any sharp objects attached to draperies.
4. Run underweight loads. **DO NOT OVERLOAD.**
5. Give short run without adding moisture:  
    White spirits...10 or 15 min. or  
    Perchloroethylene...5 min. or  
    Fluorocarbon...5 min.
6. Give normal extraction
7. Tumble dry. **DO NOT EXCEED 120 DEGREES FARENHEIT (50 DEGREES CELCIUS) TUMBLER TEMPERATURE!!!**
8. Hang immediately. Do not leave in hamper.

CAUTION: If draperies are cabinet/air dried, do not place coated side over the bar – place fabric side over bar. If the drapery is damp with solvent or water and is folded so that the coated side comes in contact with itself, the fabric may self-stick while drying and then shred or tear the foam when you try to separate it.